



The Fast Cleaning Concept

Premium Kitchen Cloth



The special structure of the Kitchen Cloth makes it dry fast. It's important for a cloth use in the kitchen area where a lot of food leavings are picked up and retained in the cloth. When the cloth dries fast it leaves less time for bacteria to multiply.

The rib-knitted Kitchen Cloth picks up and retains larger particles like bread crumbs.

The Kitchen Cloth is made of 100% ACTEX®. ACTEX® is ACT's own microfibre material and has a 2 – years performance guarantee.

Material

ACTEX®. 2 years performance guarantee.
Approved according to Öko-Text standard 100.
80% Polyester, 20% Polyamide

Size: Approx. 27 x 32 cm 10.6 x 12.6 in

Weight: Approx. 23 g 0.8 oz

Art.no.:	Description:	Colour:
600083830	Kitchen Cloth	Apple
600083930	Kitchen Cloth	Grape



How do you use the Premium Kitchen Cloth?

Fold the cloth twice and you will have eight clean surfaces to use.

Put your whole hand on the cloth and wipe with light sweeps. Never bunch the cloth up.

To remove and pick up dry dirt, such as bread crumbs, use the Kitchen Cloth dry.

To remove spots, such as milk or grease, use the Cloth moistened with water.

Due to the effectiveness to remove and hold grease and dirt it is important to change and wash the Kitchen Cloth regularly.

Where do you use the Premium Kitchen Cloth?

Kitchen table, working areas and cupboards.

Stove, zink, kitchen fan, taps.

Stainless steel and kitchen fixtures.

Care:



Machine wash at up to max 92°C, 198°F.

Tumble dry at up to max 92°C, 198°F.

Never use chlorine or other bleaches.

Use an environmentally friendly detergent.

Never use softeners in the rinse water.

Wash separately because the products will otherwise gather lint from other fabrics.